



Adapter API RP 1004

Mod. 1526 & 1526R




APPLICATION

It's a Safety accessory in accordance with Directives ATEX 2014/34/EU and PED 2014/68/UE. The adapter API RP 1004 is used to prevent any possible leaking during the process of transferring fluids during the loading/dischage of tank trucks. There are two versions of the adapter, with and without a lever for manual opening.



CHEMICAL SUITABILITY

- Standard Model is for traditional fuel without additives or compatible chemical products

PARTS	1526	1526 R
BODY	ALUMINIUM	ALUMINIUM
INTERNAL COMPONENT	STAINLESS STEEL	STAINLESS STEEL
CONNECTION	API RP 1004	API RP 1400
GASKET/OR	NBR (VITON® on request)	NBR (VITON® on request)
LEVER	-	ALUMINIUM
MAX WORKING TEMPERATURE	- 20°C + 60°C	- 20°C + 60°C
MAX WORKING PRESSURE	5 bar	5 bar
MAX FLOW RATE	2500 L/MIN	2500 L/MIN



CE 477 Ex II 3 G



DIMENSIONS			
Code	DN1	DN2	A
1526-00	4" API RP 1004 F	3" BSPP M	170
1526-02	4" API RP 1004 F	3" R M	170
1526-04	4" API RP 1004 F	4" BSPP M	170
1526-08	4" API RP 1004 F	3" BSPP M	175

INSTALLATION

- For correct installation follow the Directives and product User Manual.
- For custom application or maintenance write to: quality@ridart.it
- Declaration of Conformity and User Manual are available on: www.ridart.it/support

MAINTENANCE

- Periodically check the device is necessary to remove possible dirty.
- Always replace the product after fire or deflagration.
- In case of tampering warranty expires and safety protection is not guaranteed.

RIDART s.r.l. via Adua, 17 - 21045 Gazzada Schianno (VA) ITALY P.IVA/C.F. IT 01454770122
www.ridart.it info@ridart.it +39 0332 463301

Product Certification, Declaration of Conformity, User Manual and Testing on: www.ridart.it/support
 The Data and Images are not binding. We reserve the right to make changes without notice. Pressure & Flow Tolerances ±20%.